

Kayak Rack Assembly Instructions

Atlantic Aluminum & Marine Products, Inc.
 221 S 3rd Street Lantana, FL, US, 33462
 Call: (561) 310-4360
 Fax: (561) 533-8017
 Email: jtellex@floatstep.com



STEP 1 - In order to minimize the shipping costs of the kayak rack the two upright long pieces have been cut into two smaller pieces (each labeled).



STEP 5 - Remove the vice grips from the sleeve and then stand the upright on end and tap the end on a solid surface until the two pieces are joined together



STEP 2 - First, put the two kayak arms on the upright before joining together.



STEP 6 - Slide the one top kayak arm above the tape before proceeding.



STEP 3 - A sleeve insert is in one of the pieces which is slotted to allow compression



STEP 7 - Attach the bungee cord loop with one self tapping screw on each piece (on either side of the seam). See predrilled holes.



STEP 4 - Squeeze the sleeve with vice grips and slide the two pipes over the slotted sleeve until they touch the vice grips.



STEP 8 - The J Bracket on the bottom requires one EZ Dock hardware connector for installation on dock or wood mounts use lag bolts